

Standoflex Plastik-Reiniger antistatisch Plastic Cleaner antistatic

- Solvent blend cleaner with antistatic effect
- For plastic substrates

Technical Description:

• For preliminary cleaning of plastic substrates

Standoflex Plastic Cleaner antistatic

Substrate:

• New plastic parts

Application: Antistatic cleaning agent



Apply by means of a soaked cloth or spray can and remove with a clean, dry cloth.

Pretreatment / **Cleaning:**



For substrate preparation see Standox Painting System S1



Use air fed respirator. Refer to relevant Health and Safety Data Sheets.

Standoflex Plastic Cleaner antistatic

Flash point:

• 26°C / 78.8°F

Specific Gravity:

• 0.76 g/cm^3

VOC (2004/42/EC):

2004/42/IIB(a)(850)770
The EU limit value for this product (productcategory IIB.a) in ready to use form is max 850 g/l VOC. The VOC content of this product in ready for use form is max. 770 g/l.

Important remarks:

- Do not allow Standoflex Plastic Cleaner antistatic to dry on surfaces.
- Change cloths often.
- Must be left to evaporate or be heated to remove from porous plastic substrates.

For professional use only! The information provided in this documentation has been carefully selected and arranged by us. It is based upon our best knowledge on the subject at the date of issuance. The Information is given for information purposes only. We are not liable for its correctness, accuracy and completeness. It is up to the user to check the information with regard to up-to-dateness and suitability for his intended purpose. The intellectual property in this Information, including patents, trademarks and copyrights, is protected. All rights reserved. The relevant Material Safety Data Sheet and Warnings displayed on the product label need to be observed. We may modify and/ or discontinue operation of all or portions of this Information at any time in our sole discretion, without notice and assume no responsibility to update the Information. All rules set forth in this clause shall apply accordingly for any future changes and amendments.